



### Installation Instructions for RS-485 Termination Resistors

Accutech recommends the use of 120Ω terminating resistors. Leaded termination resistors are provided with all Accutech RS-485 devices.

For more information, see: TSN03891 – Technical Support Notice – Accutech – RS-485 Wiring Guideline.

